



## Installation and operating instructions

### SPS 06 – Outdoor Shower Column Cylindrical

#### BASIC TECHNICAL DATA

Water inlet:	G 1/2" internal thread
Water pressure:	0.2 – 0.6 MPa
Recommended water pressure:	0.3 MPa
Water flow time:	about 15 seconds
Dimensions:	2424 x 268 x 268 mm
Weight:	21 kg

#### Shower column functions

- SPS 06 is an all stainless steel shower column with hot and cold water supply. Water temperature can be controlled by a mixing valve. The water flow is managed by a pressure valve.

#### Installation

- The column is designed for installation on a concrete surface.
  1. Drill holes according to the anchor bracket with a diameter of 12 mm.
  2. Use the supplied threaded bars to anchor the column to the chemical anchor.
  3. Connect the water supply.
  4. Place the column on the threaded bars.
  5. Fasten the column using the nuts provided.

#### Safe operation

- When installing the shower column outdoors, it is necessary to drain the water from the shower before the winter season (water must not remain even in the valve - blow out with pressurized air), or dismantle the entire shower and store it in a building with a temperature above freezing. When the water in the pressure valve freezes, it will be irreparably damaged.

#### Maintenance and cleaning

- The device was made from the stainless steel of quality corresponding with ČSN 17 346 (AISI 316) standard and, therefore, it must not be operated in chemically-aggressive environment and
- **Preparations containing chlorine must not be used for its cleaning!!**
- Cleaning agents by WÜRTH are recommended:
  - Metal renewal agent - Order No. 893 121 1
  - Stainless steel spray treatment - Order No. 0893 121 - K.
- No other methods of cleaning and assembly of the product not specified here are permitted.

